

# Elevator Interface

## *Mailmobile® System Delivers Like Clockwork to Routes on Different Floors*

Mailmobile speaks your elevator system's language, and uses elevators to complete a route on multiple floors. Whether adapted to existing elevator systems or installed in new construction, Mailmobile's elevator interface extends automated delivery to every critical point in your facility.


### *How does it work?*

When it comes to using an elevator, the Mailmobile system works like its human counterparts—by pushing buttons. Except the Mailmobile pushes buttons electronically by communicating through the Elevator Supervisor.

A Mailmobile or Packmobile™ arrives at an elevator, calls the elevator, enters the elevator, and requests the proper floor to resume its route or to make a special delivery, depending on its programmed task. Reaching the proper floor, the Mailmobile exits the elevator and continues its appointed task, releasing the elevator for others to use.

### *Cooperative Team Effort*

Our engineering staff works directly with your facilities manager and elevator maintenance company to add specialized communication hardware to your elevator, resulting in an efficient, effective and reliable link between Mailmobile and your elevator system.



### *Interfaces with a Variety of Elevators*

Some elevators are the pass-through type. Others may require the Mailmobile to do a tight U-turn on the elevator, or to back out. Mailmobile adapts to your situation.

Interface includes:

- Elevator Supervisor (interface with elevator system)
- Supervisor Software
- Mailmobile to Supervisor Communication Hardware
- System configuration, installation, and testing

**egemin**  
AUTOMATION

**BELL+HOWELL**

Mailmobile

11818 James Street  
Holland, MI USA  
49424  
616-393-0101

